



# Aerosol composition and processing Surface-Atmosphere Integrated Laboratory (SAIL) campaign


Maria A. Zawadowicz, Brookhaven National Laboratory

with contributions from: Chongai Kuang, Ashish Singh, Janek Uin, Rebecca Trojanowski, Arthur J. Sedlacek III and Olga Mayol-Bracero

October 26, 2022








#### ARM Aerosol Observing System (AOS)

- •Self-contained platform (20-ft shipping container) for ground-based aerosol (and trace gas) measurements
- •Part of larger ARM sites, 5 AOSes (fixed sites and mobile facilities)
- •Stack (aerosol inlet) height ca. 30 feet (10-m) above ground level.
- •Inlet particle size cut (0.016 6.2 μm)
- •Deployed in diverse locations and climate regimes since 1996.











#### AOS Measurements during SAIL




- AOS installed on Crested Butte Mountain
- In-situ measurements of aerosol number, composition, optical properties, size distributions and hygroscopicity
- Weather station on top of the container






#### Aerosol chemistry measurements during SAIL





#### PMF PI product procedure

Unconstrained PMF algorithm performed 350 times





Rolling PMF of the whole ACSM SAIL dataset using the ME-2 algorithm with biogenic SVOOA constrained and two free factors

 ACSM mass spectra were factorized into source profiles using positive matrix factorization (PMF)




#### PMF PI product procedure









## PMF PI product procedure









#### Periodic long-range transport of wildfire emissions





Supersaturation


## Periodic long-range transport of wildfire emissions















# "Clean" regime emissions are a mixture of regional and local processed aerosol







## Funded FICUS proposal: Characterization of the Aerobiome During ARM SAIL Campaign





 "Simultaneous vertically resolved profiles of fluorescent aerosol concentrations, accumulation and coarse-mode size distributions, and samples of aerosol for subsequent analysis with highresolution mass spectrometry and microscopy at the Environmental Molecular Sciences Laboratory (EMSL) for identification of specific particle morphologies, chemical compositions, and biomarkers."

